

Bosch Video Management System Software V. 3



- Enterprise-class Client/Server based video management system
- System-wide user management, alarm handling, health monitoring, and configuration
- Full virtual matrix capabilities, including analog monitor support and CCTV keyboard control
- Superior alarm handling with alarm priorities and selectable user group distribution
- Advanced user interface concepts for effective and efficient operation
- Bosch Workstations and Servers recommended for optimal system reliability and performance

The Bosch Video Management System is a unique enterprise IP video security solution that provides seamless management of digital video, audio, and data across any IP network. It is designed to work with Bosch CCTV products as part of a total video security management system. You can integrate your existing components into one easy-to-manage system, or use our full-line capabilities and benefit from a complete security solution based on cutting-edge technology and years of experience.

The Bosch Video Management System is installed on a Microsoft Windows Operating System.

We recommend using Bosch Workstations and Servers. They are fully tested and optimized for Bosch Video Management System.

In addition to the Bosch ST standard terms and conditions of sale, the Bosch Video Management System software is covered by the Bosch VMS Software Maintenance Agreement, which can be found in your online CCTV product catalog.

System Overview

The Bosch Video Management System contains the following software components:

 Central Server software provides management, monitoring, and control of the entire system

- Video Recording Manager (VRM) and Network Video Recorder (NVR) services provide recording and playback management of video, audio, and data
- Configuration Client software provides the user interface for system configuration and management
- Operator Client software provides the user interface for system monitoring and operation

These software components can be run together on a single PC for small systems or on separate PCs and servers for large systems.

Bosch Video Recording Manager (VRM) provides a Distributed Network Video Recorder solution, eliminating the need for dedicated NVRs, and signaling the second generation of IP Network video recording.

The VRM provides load balancing and failover for the iSCSI storage and makes it easy to add additional iSCSI storage later on. VRM introduces the concept of a storage virtualization layer. This abstraction layer enables VRM to manage all of the individual disk arrays in the entire system as a single "virtual" common pool of storage, which is intelligently allocated as needed.

The usage of multiple client workstations offers great scalability.

Bosch VMS manages 2000 IP cameras / encoders and 100 workstations out-of-the-box. It can be deployed in larger installations if required. For this contact your Bosch Design Engineer.

Functions

Deployment

- Updates of Operator Client and Configuration Client automatically deployed from Central Server
- Supports all Bosch MPEG4 & H.264 encoders, MPEG4 & H.264 IP cameras and IP AutoDome cameras in SD & HD format, decoders, Allegiant, DiBos, Bosch POS/ ATM Bridge, and DiBos-compatible ATM Bridge
- Supported HD resolutions: 720p and 1080p

Configuration

- Automatic discovery of IP devices
- Automatic IP address assignment of IP devices
- Batch firmware updates of IP devices
- Configurable Logical Tree
- Predefined camera sequences
 Pre-configured camera sequences with 25 cameras
 with each up to 100 steps with individual dwell times.
- "Automatic Sequences" created by multiple selection and drag and drop to Image panes
- · Four configurable user-event buttons

User Interface

- Zoomable sitemaps with links, devices, sequences, and Command Scripts
- Sitemaps in DWF format are used. DWF format version 5.0 and 6.0 are supported.
- Up to 4 PC monitors supported per Workstation
- CCTV keyboard support, connected to either Workstation or IP decoder
- Flexible Image panes allow any combination of video window sizes and layouts
- Any live Image pane can be switched to instant playback
- Multiple instant playback Image panes
- Image windows can display live video, instant playback video, text documents, maps, or web pages
- Device states shown by icons, including networkconnection loss, video loss, and camera de-adjustment
- Favorites tree can be individually configured per user
- Favorites tree can include complete views with Image pane layouts and camera assignments
- Camera selection by double-click or drag and drop from site maps, Logical Tree, or Favorites Tree
- · Decoders can be organized in Analog Monitor Walls
- Control of analog monitors connected to decoders via drag and drop
- Synchronized playback of up to 16 NVR cameras and up to 16 VRM cameras
- Sophisticated multi-camera timeline allows easy, graphical searching of stored video
- Timeline colors indicate recording status normal recording, alarm recording, motion recording, protected recording, and audio recording (not for cameras managed by a VRM)
- · Easy clip selection by dragging hairlines in the timeline
- Selected clips can be exported to DVD, network drives, or USB sticks with a few mouse clicks
- Flexible search works across all NVRs and DVRs connected to the system
- Post-recording motion search allows changes to selected areas of the image to be easily located

- Forensic Search allows the usage of Intelligent Video Analysis (IVA) algorithms on the recorded video
- Two audio listening options selected channel only, or multiple simultaneous channels
- Audio Intercom functionality
- 4:3 and 16:9 Image panes
- Continuous Operation for live, playback and export while Central Server disconnected
- Live and Playback of the following recording engines: Video Recording Manager, Local Storage, Dircet-iSCSI-Recording, Bosch Recording Station. For migration purposes: NVR, DiBos, Vidos NVR

Scheduling

- Up to 10 Recording schedules with Holidays and Exception Days
- Task Schedules with Holidays, Exception Days, and recurring schedule support
- Per camera settings for minimum and maximum recording times
- Per camera, per recording schedule frame rate and quality settings for live, normal recording, motion recording, and alarm recording

Event Handling

- Event list with device events (e.g. video loss), system events (e.g. disk full), SNMP traps from network devices (e.g., heavy network traffic), subsystem events (e.g. Allegiant alarm), user events (e.g. logon failure), schedule events (e.g. every Tuesday at 10:15), etc.
- Compound events (combining events with Boolean logic)
- Event duplication allowing separate handling
- Event allocation to user groups
- Schedule dependent alarm generation
- Schedule dependent event logging
- Schedule dependent event-generated Command Script invocation

Alarm Handling

- Alarms can trigger alarm-mode recording for any cameras
- 100 alarm priorities
- Selective auto-popup on alarm
- Alarms displayed in separate alarm window
- Up to 5 Image panes per alarm with live or playback video, sitemaps, documents, or web pages displayed in an "alarm row", with highest priority alarms on top
- Audio file per alarm
- Workflow with user instructions and user comments, optionally forced before clearing
- · Email or SMS notification on alarm
- Alarm display on analog monitor walls
- Alarm auto clear options either time or state dependent

User Management

- LDAP compatible for integration with enterprise user management systems such as Microsoft Active Directory
- Access to system resources individually controlled per user group
- Logical Tree customized per user group users only see devices for which they have access

- User group rights for protecting, deleting, exporting, and printing video
- User group rights for Logbook access
- User group priority assignment for PTZ control and Allegiant camera access
- Individual per-camera privileges assignable per user group for live access, playback, audio, meta data display, dome control
- Dual-authorization logon special privileges and priorities granted when two users log on together

System Monitoring

- System-wide health monitoring, including cameras, computers, software, and network equipment
- Network equipment and other third-party devices monitored with SNMP

Customization and Interfacing

- Custom Command Scripts can control all system functionality
- Built in Command Script editor supporting C# and Visual Basic .Net
- External software can trigger events and send metadata via "Virtual Inputs"
- Any .Net programming language (C#, JScript, etc.) or COM programming language (C++, Visual Basic, etc.) can be used to trigger Virtual Inputs
- Other systems can control the virtual matrix with Allegiant CCL commands that can be sent via RS232
- Compatible with Bosch Building Integration System
- Compatible with Advantech ADAM-6000 series Digital Input / Output modules

Parts Included

- The Base Box is delivered with DVD and Quick Start Manual.
- The DVD contains the following items:
 - Installation program that can selectively install all components (Central Server software, Network Video Recorder software, Video Recording Manager software, Configuration Client software, Operator Client software) in all supported languages
 - Configuration Manual (PDF format) in all supported languages (except Arabic)
 - Operator's Manual (PDF format) in all supported languages (except Arabic)
- Quick Start Manual in English, French, German, Simplified Chinese and Spanish

Licenses are provided as eLicenses via email.

Technical Specifications

System Specifications

| Maximum number of workstations simultaneously viewing the same camera | Multicast: 20 Unicast: 5 |
|---|---|
| Supported languages | English, German, Dutch, Italian, Portuguese, French, Spanish, Simplified Chinese, Traditional Chinese, Russian, Hungarian, Japanese, Czech, Danish, Finnish, Greek, Norwegian, Polish, Swedish, Thai, Turkish. Korean, and Arabic |

Anti-Virus software must not perform a full-scan. Performance may decrease depending on configuration.

| Event reaction time | <1 second, assuming sufficient network bandwidth |
|--|---|
| Alarm reaction time (incl. 1 live Image pane, 1 instant playback Image pane and 1 map Image pane): | Maximum 2 seconds, assuming sufficient network bandwidth |
| Bandwidth requirements | Min. 1 Gbps for connections between: Operator Client to Central Server Operator Client to NVR/VRM/DiBos Central Server to NVR/VRM/DiBos |

Required open ports

Connection from Central Server and Client Workstations to NVRs:

Selectable TCP ports (default 5390, 5391, 5392, 5393)

Connection to Operator Client Workstations by BVMS SDK: One selectable TCP port (default 5394)

Connection from Central Server to SMTP (for email notifications): $\ensuremath{\mathsf{TCP}}\xspace$ Port 25

Connection to Bosch encoders and decoders:

Control channel: TCP ports 80 and 1756 Network scan: UDP ports 1757 and 1758 Multicast detection: one selectable UDP port (default 1900)

Multicast video transmission:
For each encoder audio or video stream, 1 selectable UDP port

Unicast UDP transmission: UDP ports dynamically assigned in the range from 1024 to 65000

Connection to DiBos DVRs (uses DCOM):

TCP Port 135 plus four TCP ports and four UDP ports dynamically assigned in the range from 1025 to 65535

| Maximum number of sustained | For highest performance server, |
|---|--|
| events | e.g. MHW-S380R6-HC: |
| | 5,000 events/s at peaks |
| | 2,500,000 events/h received 500,000 events/h thereof written |
| | to the system log (Logbook) |
| Logbook | Supported by SQL Server 2008 R2 |
| | (32-bit or 64-bit version) |
| 0 1 10 | 4 GByte Logbook size |
| Central Server Redundancy | Available with VMware HA. Please contact Bosch Design Engineer for |
| | redundancy solutions. |
| Maximum number of Task Schedules | 200 |
| NVR Specifications | |
| For new system designs refer to VRM For NVR-like systems requirements u | l specifications. ıse DLA storage with VRM preloaded. |
| Maximum number of cameras and da | |
| for advanced performance server, e. DVA-8K,DVA-16K (AV multistream o | |
| Continuous or motion or alarm re- | 64 cameras @ 25 IPS / 4 CIF / |
| cording and 4 playback clients with 4 Image panes each: | 2 Mbps |
| Continuous (1IPS) and motion or | Continuous recording: |
| alarm recording and 4 playback clients with 4 Image panes each: | 64 cameras @ 1 IPS / 2 CIF / 1,5 Mbps |
| ents with 4 image panes each. | Motion or alarm: |
| | 64 cameras @ 25 IPS / 4 CIF / |
| AA C SI C L | 2 Mbps |
| Motion with pre-motion and alarm with pre-alarm recording and 4 | Pre-motion / alarm recording: 64 cameras @ 1 IPS / 2 CIF / |
| playback clients with 4 Image panes | 1,5 Mbps |
| each: | Motion / alarm: |
| | 64 cameras @ 25 IPS / 4 CIF / 2 Mbps |
| Redundancy | Failover NVR can be assigned to |
| • | take over for a failed NVR. Multiple |
| | Primary NVRs can be assigned to th |
| | same Failover NVR. Redundant NVF can be assigned to a Primary NVR. |
| Maximum number of Primary NVRs | 2 |
| serviced by a Failover NVR | |
| Maximum number of NVRs per Cen- | 2 |
| tral Server | For higher camera numbers use VRM. |
| Device compatibility | H. 264 encoders and cameras are |
| Device compatibility | not supported for NVRs. |
| | |
| VRM Specifications | |
| VRM Specifications Maximum count of VRM servers per Central Server | 40 |

neer for iSCSI storage solutions.

Max. number of playback sessions

Minimum Client Workstation PC Requirements

| Operation System | Windows XP Professional, Service Pack 3 (32-bit only) Windows 7 Professional or Ultimate SP1 64 bit version (required for > 500 cameras) |
|---------------------------|--|
| CPU | Intel Core 2 Duo |
| RAM | 2 GB or greater |
| Free disk space | 500 MB or greater We recommend having minimum 15% free disk space. |
| Network card | 1000Base-T |
| Display Resolution | Minimum per monitor 1024x768, 1280x1024 or greater recommended |
| Recommended Graphic Cards | MHW-AWGC-Q2000 MHW-AWGC-Q4000 MHW-AWGC-ATIV38 MHW-AWGC-ATIV58 MHW-AWGC-Q600 |

Maximum Graphic Cards Specifications

You find detailed information on the maximum number of Image panes and the CPU load for various workstations or servers and graphic cards in the Application Guide "Display performance indication".

Minimum Central Server PC Requirements

| Operation System | Windows 2008 Server R2 SP1 (64- bit) required for > 500 cameras Window 2003 Server R2 SP2 (32- bit only) For All-in-one systems and maxi- mum 64 IP cameras/encoders: Windows XP Professional, SP3 (32- bit only) or Windows 7 SP1 (64-bit only) |
|--------------------|--|
| CPU | Intel Core 2 Duo |
| RAM | 4 GB or greater 8 GB for systems > 500 cameras |
| Free disk space | 15 GB or greater We recommend having minimum 15% free disk space. |
| Network card | 1000Base-T |
| Display Resolution | 1024x768 or greater |

| Operation System | Windows XP Professional, SP3 (32- bit only), Windows 2003 Server, R2 SP2 (32-bit only) Windows 7and Windows Server 2008 not supported |
|------------------------------------|---|
| CPU | Intel Core 2 Duo |
| RAM | 2 GB or greater |
| Free disk space | 500 MB + Video Storage We recommend having minimum 15% free disk space. |
| Hard disk drives | Minimum: separate partition for video storage Separate drive for video storage recommended |
| Network card | 1000Base-T |
| Display Resolution | 1024x768 or greater |
| Minimum VRM Server PC Requirements | |
| Operation System | Windows 7 Ultimate SP1, Professional Edition SP1 64-bit versions Windows Server 2003 R2, Standard Edition, 64-bit versions Windows Server 2008 R2, Standard Edition 64-bit versions Windows Storage Server 2008, Standard Edition 64-bit versions |
| CPU | Dual-Core Intel Xeon Processor 5110 (1.60 GHz, 1066 FSB) to Quad-Core Intel Xeon Processor E5430 (2.66 GHz, 1,333 FSB) |
| RAM | Minimum 2 GB |
| Free disk space | 500 MB We recommend having minimum 15% free disk space. |
| Network card | 1000Base-T |
| Display Resolution | 1024x768 or greater |
| Device Compatibility | |
| Analog Matrix Switch | Bosch Allegiant series, firm- ware 8.75 or later and Master Con- trol Software version 2.91 |
| CCTV Keyboard | Bosch Intuikey (KBD-Universal or KBD-Digital), firmware version 1.95 |
| Digital I/O | Digital I/O Advantech ADAM-6050, ADAM-6052, ADAM-6060, ADAM-6066 |
| Digital Video Recorder | Bosch Recording Station 8.9 DiBos, firmware version 8.7 Maximum 50 DiBos recorders per Central Server |
| USB to Serial adapter | Belkin serial adapter cable F5U103vea |

| Ethernet to Serial adapter | Comtrol DeviceMaster RTS 4-Port |
|--|--|
| IP Devices | VIP-X Series encoders and cameras H.264 Series encoders and cameras MPEG-4, H.264 Main Profile, H.264 Baseline Plus are supported (H.264 Baseline and MPEG-2 not supported) |
| Ordering Information | |
| Demoversion - Non Expandable 1 Forensic Search included. | MBV-BDEM-30 |
| Lite-32-Edition - Non Expandable Supports 32 Cameras, 2 Workstat CCTV Keyboard, 0 DVRs – Non Ex 1 Forensic Search included. | tions, 1 |
| Lite-64-Edition - Non Expandable Supports 64 cameras, 4 Workstat 2 CCTV Keyboards, 0 DVRs – Non ble 2 Forensic Search included. | ions, |
| Professional Edition Supports 8 Cameras, 2 Workstatio CCTV Keyboard, 1 DVR All MBV-X* and MBV-F* can only be with the Professional Edition. 1 Forensic Search included. | |
| 1 Channel Expansion Expansion, order the exact number For example, if you order 128 unit use 128 cameras/decoders in you VMS. Only those cameras need be which are shown in the Logical Trees. | is you can Ir Bosch counted |
| 1 Workstation Expansion Expansion, order the exact number | MBV-XWST-30 er required. |
| 1 DVR Expansion Expansion, order the exact number | MBV-XDVR-30 er required. |
| 1 CCTV Keyboard Expansion Expansion, order the exact number | MBV-XKBD-30 er required. |
| 1 Forensic Search Expansion Expansion, order the exact number You need one license per Worksta | • |

per camera or encoder.

Allegiant Matrix Connection

ATM/POS Connection

Base Box

Expansion Box

OPC Server Connection for BIS

Paper box including Setup DVD

Hard cardboard box including DVD and Quick Start Manual (in English, French, German, Simplified Chinese, and Spanish) MBV-FALG-30

MBV-FATM-30

MBV-FOPC-30

MBV-BBOX

MBV-XBOX

| Ordering Information | |
|---|------------|
| Services | |
| Maintenance Lite-32-Edition | MBV-MLIT32 |
| Maintenance Lite-64-Edition | MBV-MLIT64 |
| Maintenance Professional Edition | MBV-MPRO |
| Maintenance Channel Expansion | MBV-MCHAN |
| Maintenance Workstation Expansion | MBV-MWST |
| Maintenance DVR Expansion | MBV-MDVR |
| Maintenance CCTV Keyboard Expansion | MBV-MKBD |
| Maintenance Forensic Search Expansion | MBV-MFOREN |
| Maintenance Allegiant Matrix Connection | MBV-MALG |
| Maintenance ATM/POS Connection | MBV-MATM |
| Maintenance OPC Server Connection | MBV-MOPC |

Americas:
Bosch Security Systems, Inc.
130 Perinton Parkway
Fairport, New York, 14450, USA
Phone: +1 800 289 0096
Fax: +1 585 223 9180
security,sales@us.bosch.com
www.boschsecurity.us

Europe, Middle East, Africa: Bosch Security Systems B.V. P.O. Box 80002 5600 JB Eindhoven, The Netherlands Phone: + 31 40 2577 284 Fax: +31 40 2577 330 emea.securitysystems@bosch.com www.boschsecurity.com

Asia-Pacific:
Robert Bosch (SEA) Pte Ltd, Security Systems
11 Bishan Street 21
Singapore 573943
Phone: +65 6571 2808
Fax: +65 6571 2699
apr.securitysystems@bosch.com
www.boschsecurity.asia